



# Bright House Networks Navigator makes finding what you want to watch as easy as

With the Bright House Networks Navigator, you have a convenient way to discover all that Digital Cable has to offer.

The Navigator makes virtually anything you want to find accessible via the “A,” “B,” or “C” buttons. And for DVR customers, the Navigator gives you convenient controls for simplified recording.

At Bright House Networks, we’re committed to delivering cutting-edge technology to your home that you can’t get elsewhere.

See how BRIGHT life can be!

Press “B” for what’s playing now or later.  
Search by:

- Category
- Rating
- Title

Press “A” for what’s playing now.  
Search by:

- News & Weather Now
- Sports Now
- Kids Now
- HDTV Now

Press “C” to take a step back.  
It will take you back to the previous menu, screen or program. It’s like an Internet browser back button.

Move left, right, up, down.  
Use the arrow keys to navigate through menus.  
Press “Select” to make a choice.

Press “A” for Access Menu.  
Choose one of the following:

- What’s on now
- HDTV Now
- On Demand programming
- DVR Show List
- Answers on Demand



Watch



Talk



Surf

**bright house**  
NETWORKS





# Navigator Features Quick Guide



CSI: Miami on A&E

## Is for Access Menu.

- Press "A" on your Digital Remote for access to what's on now, Favorite Channels, all On Demand programming and much more.
- Use the genre categories along the bottom of the screen to view shows that are playing right now in News & Weather, Sports, Kids and HDTV.



Sons of Hollywood on A&E

## Press B to Find Programming.

- When using the Guide, just press "B" and you can search current and upcoming programming by category, title or rating.



Sons of Hollywood on A&E

## C Your Back Button.


- Press "C" on your Digital Remote to return to the previous menu, screen or program.



Mega Movers on The History Channel


## Record a Series (for DVRs only).

- To record a series in the future, find its title in the Guide.
- Press "Select" on your Digital Remote.
- When the Select Options screen displays, arrow down to Record Series with Options and press "Select." Customize any details you wish, and press "A" to save.
- The show's title will appear in red and the Series Recording icon will be displayed.



## How to find the DVR Recorded Show List (for DVRs only).


- Press "List" on your Digital Remote to get your recorded list.
- Or press "A" for the Access Menu, arrow to the "DVR Show List" and press "Select."
- Arrow left/right along the bottom list to see shows listed by date, title, or scheduled recordings, or to get Series Manager or Recording Log.
- Then, "Select" a show from the left column.



The Sopranos on HBO

## Improved Parental Control.

- Now you can block programming by content using the new content advisory (language, violence, etc.), rating (TV-PG, TV-14, TV-MA, etc.), channel, time or title.
- Press Settings, then use the right arrow to highlight Parental Control.
- Choose the blocking parameters you want.
- Press "C" to save your settings.
- Use the up arrow to TURN ON/OFF, press "Select" and enter your 4-digit code (which will be 0000 unless you change it in Settings) to activate your Parental Control.



Entourage on HBO

## Keyboard Search.

- Already know the name of the show you want to watch? Just press "B" twice to bring up the keyboard and spell the show name using the left, right, up and down arrows on your Digital Remote.
- Press "Select" to choose the highlighted letter.
- When title appears in the left column, use the left arrow key to switch from the keyboard to the title list; use up/down arrows to highlight your program. Press "Select" to view, record, record a series or set a reminder.